



#### **AXTracker MMT Certifications:**

Intrinsic Safety (UL Class 1, Division 1 Groups A, B, C, D) for US and Canada

FCC CFR Parts 15 and 25

Industry Canada

CE Mark (European Certification)

#### Standards:

**SAE J1455** 

MIL STD 810

NEMA 4X / IP67

## **AXTracker MMT Setup:**

Use a PC, the Tracker Setup Program and the Axonn Wireless Configuration Tool.

#### Setup Options include:

- · Up to 12 different reporting intervals
- Interval or 24 hour operation mode
- · Interval Override scheduling
- · Motion Sensor Setup and scheduling
- · Delay To Start
- · Statistics messages

All available in the Tracker Setup Program communicating wirelessly with the MMT.

# **Feature Set:**

## **Supervisory position reporting:**

- Wake, GPS locate, Transmit location, Resume sleep
- Up to 12 programmable sleep intervals or time-of-wake settings

#### Interval override:

- Alternate supervisory reporting schedule triggered by "alarm" or motion
- Transmits GPS location on alternate interval for programmed time or while alarm remains active

# Integrated motion sensor:

- · Message on start and stop
- Engage interval override on motion for set time or while in motion

# Messaging cost reduction feature(Stationery Report Rate):

Reduced satellite messaging if asset remains in same location

## **Geo-Fencing:**

- Report region match on location determination
- Engage interval override on region match fail

## Field Replaceable battery pack:

- 7 year battery life (2 updates/day)
- · Field replaceable

# Wireless configuration

 Setup MMT via the Wireless Configuration Tool

## **Accessories:**

Wireless Configuration Tool and USB cable

Installs in minutes using automotive adhesive tape or screw mounting

Global LEO Satellite operation using the Globalstar Simplex Data Network

